



- Pos. 1 VA Sturzbügel
- Pos. 2 5x VA Scheibe U10
- Pos. 3 2x VA Inbusschraube M10 x 25
- Pos. 4 1x VA Inbusschraube M10 x 30
- Pos. 5 1x VA Inbusschraube M10 x 50
- Pos. 6 1x VA Sechskant-Mutter M10