

Installation Instruction

Handlebar Risers 23569

Fit for:

BMW R1200GS 2008-2012

BMW R1200GS Adv. 2008-2013

Shipment includes:

2x handlebar riser lower part

2x handlebar riser upper part

4x hexagon socket screw M8x 30

2x hexagon socket screw M10x45

1x European street homologation

1x installation instruction

Dismantling:

First, remove the upper part of the handlebar fixation (clamps) from the triple clamp. Then, remove the lower part.

Mounting:

The handlebar risers (lower parts) will directly be mounted on the triple clamp under the handlebar. Please use the enclosed M10x35 screws. The handlebar risers (upper parts) will be mounted when the handlebar is in a correct position. Please use the enclosed M8x30 screws and fix them evenly.

Screws and safety:

The enclosed screws have to be fixed with the following torque:

M8 -> 23Nm

M10 -> 46Nm

Remarks:

After having mounted the handlebar risers, please check if the brake lines, bowden cables and other cables are in a good condition. They must not tense or rub even with full steering angle. If necessary, please protect them.

