

PORTAPACCO SPECIFICO - SPECIFIC HOLDER
 PORTE-PAQUET SPÉCIFIQUE - SPEZIFISCHER TRÄGER
 PORTA-EQUIPAJE ESPECÍFICO

BMW F800R 2009

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS
 INSTRUCTIONS DE MONTAGE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE

1



SUPPORTO
 SUPPORT
 SUPPORT
 HALTERUNG
 SOPORTE

Q.TY n.2(Dx-5x)

2



SUPPORTO
 SUPPORT
 SUPPORT
 HALTERUNG
 SOPORTE

Q.TY n.1

3



VITE TEF M8x70mm
 SCREW
 VIS
 SCHRAUBE
 TORNILLO

Q.TY n.2

4



VITE TBEI M8x65mm
 SCREW
 VIS
 SCHRAUBE
 TORNILLO

Q.TY n.2

5



VITE TSCEI M6x20mm
 SCREW
 VIS
 SCHRAUBE
 TORNILLO

Q.TY n.4

6



DADO A.B. M6
 FLANGIATO
 BOLT M6
 ECRUJ M6
 MUTTER M6
 TUERCA M6

Q.TY n.4

7



DISTANZIALE Ø18x40mm
 Foro Ø8,5mm, V490
 SPACER
 ENTRETÔISE
 DISTANZSTÜCK
 DISTANCIADOR

Q.TY n.2

8



DISTANZIALE Ø18x18mm
 Foro Ø8mm, V545
 SPACER
 ENTRETÔISE
 DISTANZSTÜCK
 DISTANCIADOR

Q.TY n.2

9



RONDELLA Ø8x14mm
 WASHER Ø8x14mm
 RONDELLE Ø8x14mm
 SCHEIBE Ø8x14mm
 ARANDELA Ø8x14mm

Q.TY n.2

