

## GPS Mounting



**NH1-7-S**

The handlebar of the RnineT is fixed with M10 screws at the front and with M8 screws at the back. The best possibility to mount a GPS on a RnineT is at the front of the triple clamp.

You screw the GPS ball into the upper triple clamp. The screw is 100 mm long with a M10 thread. You can mount many different GPS mounts to it, for example RAM mounts or the mounts which we offer under Extra GPS Mount. Diameter RAM ball: 1 inch (2,54 cm)

For BMW RnineT, RnineT Scrambler, Pure, Urban G/S & RnineT /5!  
Not for RnineT Racer!

For a M8 thread, see part number NH 1-10 !

Also referred to as GPS mount, GPS bracket, GPS handlebar bracket.

**Art-Nr.: NH1-7-S**

**30,00 EUR**

GPS Mounting silver

**Art-Nr.: NH1-7M10**

**30,00 EUR**

GPS Mounting black

### Additional pictures:



**NH1-7-S**



**NH1-7M10**