

Footpeg rubber for Enduro footpegs (driver)



Footpeg rubber for Enduro footpegs (driver)

These footpeg rubbers protect the soles of your motorcycle boots and prevent premature wear.

The footrest rubber is simply screwed on from below – see photo. Use threadlocker (e.g. article no. L.10004020) for secure installation.

For BMW R1200GS LC & R1250GS these footrest rubbers only fit the optional original BMW Enduro footrests (see pictures)! They do not fit the smaller standard footrest of the BMW R1200GS LC & R1250GS!

Art-Nr.: 07622

75,90 EUR

Footpeg rubbers (2 pieces)

Additional pictures:

